

FLUO-4 AM

Table 1 - Materials Needed	Most Items Available from ION Biosciences		
Name	Volume	Description/Purpose	
Fluo-4 AM (50 µg vial)	Dry - 1 Vial	Membrane Permeable Calcium Dye Indicator	
DMS0 ¹	25 µL	Solvent for Dissolution of Dye	
100X Pluronic F-127 solution ²	100 µL	Biocompatible Surfactant for Dye Loading	
100X Probenecid solution (optional) ³	100 µL	Intracellular Dye Retention Aid	
50X TRS (optional) ⁴	200 µL	Extracellular Fluorescence Masking Agent	
 Assay Buffer - We Suggest One of the Following: ⇒ 1X HEPES-Buffered Hank's Balanced Salt Solution ⇒ 10X Brilliant Assay Buffer 	10 mL 1 mL	1X - Ready to Use Assay Buffer 10X - Concentrated Assay Buffer	
Water	As Needed	Dilution of 10X Assay Buffer (if used)	

Description

Fluo-4 is the most popular green fluorescent, intracellular calcium (Ca^{2^+}) indicator. Proven and trusted for decades to measure intracellular Ca^{2^+} flux in high throughput screening and fluorescence microscopy applications.

Laboratory Procedures

The following protocol provides general guidelines for using this dye to measure intracellular calcium. All loading conditions (dye concentration, temperature, and time) should be optimized for your specific assay, application, and instrumentation.

- 1. Allow all reagents to warm to room temperature before proceeding.
- 2. Add 25 μ L DMSO¹ to the tube containing Fluo-4 AM.
- 3. Vortex until Fluo-4 AM is fully dissolved. Centrifuge briefly to collect all contents at the tube bottom.
- Add the appropriate volume (see Table 2, next page) of 1X Assay Buffer to a 15 mL conical tube. If using 10X Assay Buffer, add the appropriate volume of Water (Table 3, next page) and 1 mL of 10X Assay Buffer to a 15 mL conical tube.
- 5. Add 100 μ L of 100X Pluronic F-127² solution to the conical tube from **step 4**.

Procedure Continues on Next Page



Laboratory Procedures (continued)

- 6. (Optional) Add 100 μ L of 100X Probenecid³ solution to the conical tube from **step 5**.
- 7. (Optional) Add 200 μ L of 50X TRS⁴ solution to the conical tube from **step 6**.
- 8. Vortex conical tube from **step 7** briefly to mix.
- Add the entire contents of the Fluo-4 AM in DMSO solution from step 3 to the conical tube from step 8 to make the Dye Loading Solution⁵.
- 10. Vortex the **Dye Loading Solution**⁵ from **step 9** briefly to mix.

Table 2Dye Loading Solution⁵	Using 1X Assay Buffer			
Name	Method A	Method B	Method C	Method D
Fluo-4 AM in DMSO ¹ Solution	25 µL	25 µL	25 µL	25 µL
100X Pluronic F-127 ² solution	100 µL	100 µL	100 µL	100 µL
100X Probenecid ³ solution (optional)	100 µL	100 µL	-	-
50X TRS ⁴ (optional)	200 µL	-	200 µL	-
1X HEPES-Buffered Hanks Balanced Salt Solution	9.6 mL	9.8 mL	9.7 mL	9.9 mL
Total	10 mL	10 mL	10 mL	10 mL

Table 3Dye Loading Solution⁵	Using 10X Assay Buffer			
Name	Method A	Method B	Method C	Method D
Fluo-4 AM in DMSO ¹ Solution	25 µL	25 µL	25 µL	25 µL
100X Pluronic F-127 ² solution	100 µL	100 µL	100 µL	100 µL
100X Probenecid ³ solution (optional)	100 µL	100 µL	-	-
50X TRS ⁴ (optional)	200 µL	-	200 µL	-
10X Brilliant Assay Buffer	1 mL	1 mL	1 mL	1 mL
Water	8.6 mL	8.8 mL	8.7 mL	8.9 mL
Total	10 mL	10 mL	10 mL	10 mL

Procedure Continues on Next Page



Laboratory Procedures (continued)

- Remove the cell culture medium and add the Dye Loading Solution⁵ from step 10. Recommend volumes are: 35 mm dish or 6-well plate, 1.5 mL; 96-well plate, 100 μL; 384-well plate, 20 μL.⁶
- 12. Incubate in a cell culture incubator at 37°C for 60 minutes.
- 13. Conduct a wash⁶ step to remove the **Dye Loading Solution**⁵ and replace with cell culture medium or assay buffer. Repeat, if necessary, to completely remove extracellular dye.
- 14. Acquire data using a fluorescence microscope⁷ equipped with GFP or FITC filters or a fluorescence plate reader using an excitation wavelength of ~490 nm, an emission wavelength of ~520 nm and an acquisition frequency of 1-10 Hz⁸. See **Table 4** below for recommended settings.

Table 4	Recommended Instrument Settings	
Setting	Recommendation	
Read Mode (Plate Readers)	'Bottom' read mode only	
Ex/Em wavelengths ⁸	~490 nm/520 nm	
Cutoff wavelength	515 nm	
Filter selection	GFP, FITC	
Contact aunaart@ionbiogoionago	am for additional recommandations and guidance on antimizing to your application	

Contact support@ionbiosciences.com for additional recommendations and guidance on optimizing to your application.

Laboratory Procedures - Footnotes

- ¹ DMSO is hygroscopic and should be stored tightly closed. Wet solvent causes difficulties with dissolution of the dye.
- ² Pluronic F-127 is a biocompatible surfactant that aids in dye dissolution, ensuring equitable dye distribution and cellular loading.
- ³ Probenecid is an anion transport inhibitor that improves intracellular dye retention. Although it is not required for all cell types and dyes, it is recommended in most cases to optimize assay performance.
- ⁴ TRS is a membrane impermeant dye useful for masking extracellular fluorescence. Caution is advised when using TRS or any other extracellular masking solutions as they may have undesirable effects on assay performance for the target of interest.
- ⁵ The Dye Loading Solution should be used within 2 hours of dye addition for best results.
- ⁶ In some cases, a no wash format works best. If a no wash format is indicated for your application, we recommend doubling the concentration of 100X Pluronic F-127, 100X Probenecid, and 50X TRS in your dye loading buffer.
- ⁷ To minimize extracellular background, the dye loading solution can be replaced with assay buffer containing 1X Probenecid solution and/or 1X TRS solution.
- ⁸ To prevent bleed-through or spectral overlap, the Ex/Em wavelengths may need to be optimized by broadening the interval between the wavelengths.



Additional Information

Dye indicator and buffer reagents can be purchased either directly from our website or by contacting our Sales Department. Custom and bulk sizes are also available. Contact Sales for more information.

Table 4	Available Reagents	Available	Available Sizes		
Name		Size	Catalog #		
		500 µg x 1 Vial	1041C		
Fluo-4 AM		50 µg x 10 Vials	1041F		
		50 µg x 3 Vials	1041G		
100X Pluronic F-127	Solution	10 mL Bottle	7601A		
100X Probenecid So	lution	10 mL Bottle	7300P-100		
50X TRS Solution		20 mL Bottle	7060A		
1X HEPES-Buffered I	Hank's Balanced Salt Solution (1X HHBSS)	100 mL Bottle	7001		
10X Brilliant Assay B	Buffer	10 mL Bottle	7010X		